



To order a complete track kit, you need to order one of each part number in the Fix & Track Kit column.

Ex: for a 1000 Prowler XTZ H2 EFI, you need 1 x 374021 & 1 x 383001.

Models	Year	Foot Note	Fix & Track Kit Part No
ARCTIC CAT UTV			
1000 Prowler XTZ H2 EFI	09-11		374021 & 383001
700 Prowler HDX	2011		374021 & 383001
700 Prowler	09-10		374030 & 383001
650i H1 Prowler	06-08		374030 & 383001
550 H1 Prowler EFI	2010		374030 & 383001
CAN AM UTV			
Commander UTV	2010		374120 & 383001
KAWASAKI UTV			
TERYX	08-11		374350 & 383001
POLARIS UTV			
RZR	08-11	E	374440 & 383200
RZR-4	2011	E	374445 & 383200
RZR-S	2011	E	374445 & 383200
RZR XP 900	2011		374465 & 383200
Ranger 800 XP/HD/CREW (with control arm susp. Type)	10-11	E	374435 & 383200
Ranger 700 EFI/HD	2009	E	374435 & 383200
Ranger 400	2011	E	374425 & 383200
YAMAHA UTV			
Rhino 700	08-11		374750 & 383001
Rhino 660	04-07		374750 & 383001
Rhino 450	07-09		374750 & 383001

E = Track kit part number is **383200**. This track kit has a smaller sprocket ratio in the rear for Polaris applications.